

Tech One

Be Creative! Direct Your Message
To Any Angle!

Material
PC + FRP & Aluminum

Weight
11 lb

Banner Size
36" x 78"
36" x 62"
40" x 75"
48" x 72"

PACKAGE CONTENTS



Vertical to horizontal • Telescopic height & Tilt function Selection of many banner sizes



1

- Place the base plate on the floor.
- Insert the center bar into the base plate.
- Loose the middle joint to extend the center bar

2

Insert the short poles and the long poles into the center hub.

3

Hang the banner from the top to the bottom.

4

- Loose the front to rotate the banner.
- Loose the rear bolt to change the leaning angle.