

# NEOS Outdoor F

FIXED TYPE / Durable Outdoor Solution!

**Material**  
Steel + FRP & Plastic

**Weight**  
14 lb

**Banner Size**  
18" x 54"~66"  
24" x 50"~60"  
30" x 46"~52"  
35" x 37"~48"  
**Wide:** 18"~35"

PACKAGE CONTENTS



Use with single or double banner • Telescopic height  
Indoor/outdoor use • Excellent stability



NEOS-F Double


NEOS-F Single

1



- Fill the hollow base tank with water or sand.
- Insert the center bar into the base tank.
- Loose the middle joint to extend the center bar

2



Insert the upper poles and the lower poles.

3



- Hang the banner from the top to the bottom.
- Loose the lower joint and push down to flatten the banner.

4

How to change the center bar position?



DOUBLE BANNER MODE



SINGLE BANNER MODE